



EK-230/B230B Ground Pile Type Clamp Earth Resistance Tester



Product Function

Earth resistance measurement, loop resistance measurement, soil resistivity measurement, earth voltage measurement, grounding down lead leakage current and grounding fault judgement.

Product features

1. Use the clamp method, 2-wire method, 3-wire method, 4-wire method, selection method and other measurement methods to measure earth resistance.
2. Equip with 2.5-inch color LCD screen, and also with USB and charge port, with storage function, clock function, automatic storage the test results 500 groups which containing the date and time.
3. Support Android system Bluetooth communication function, after installing APP can test or read test records in mobile, bring new experience.

Technical Specification

Model	EK-B230	EK-B230B
Earth Resistance Range	0.00Ω~20kΩ	0.00Ω~200kΩ
Soil Resistivity Range	0.00Ωm~9999kΩm	0.00Ωm~9999kΩm
Earth Current Range	0.000mA~20A	0.000mA~45A
Earth Voltage Range	0.0V~600.0V	0.0V~600.0V
Power Supply	DC 3.7V 2600mAh rechargeable lithium battery, full charge Approx. 4.2V	
Display Screen	2.4 inch colorful LCD screen	
Earth Resistance	Clamp method, 2-wire method, 3-wire method, 4-wire method, selection method	
Test Frequency	128Hz, 111Hz, 105Hz, 94Hz(AFC automatic frequency selection)	
Short-circuit Test Current	AC 10mA max	
Open-circuit Test Voltage	AC 14V max	
Electrode Spacing Range	1m~100m	
Clamp Jaw Size	65mmX32mm	
Auxiliary Ground Rod	4 PCS: Φ9mmX230mm	
Test Line	4PCS: red 20m, black20m, yellow 10m, green 10m	
Simple Test Line	2PCS: red 1.6m, black 1.6m	
Measurement Times	Over 5000 times(short-circuit test, after one testing must stop 30s then can test again)	
Line Voltage	Measurement below AC 600V	
Data Storage	500groups	
Audible & Visual Alarm	"Du—du—du" alarm sound	
Automatic Shutdown	5 minutes without any operation after starting up, the detector will shutdown automatically	
Shift	Automatic	
External Magnetic & Electric Field	<40A/m; <1V/m	
Resistance Measurement Frequency	>1KHz, 128Hz	
USB Communication	Only for charging	
Meter Dimension	307mm(L)X98mm(W)X56mm(H)	
Meter Weight	Tester: Approx. 1112g(include the battery); Total weight: Approx. 5.1kg(include all accessories)	
Accessories	Tester:1PC; Test ring: 1PCS; USB charge cable: 1PCS; Charger Adaptor: 1PCS; Ground stake: 4PCS; Test line: 4PCS; Simple test line: 2PCS; Tool bag: 1PCS	

